



HTL/KIN-TECH DIVISION

## SERVICE INFORMATION LETTER

TO: OWNERS/OPERATORS OF PACIFIC SCIENTIFIC  
COMPANY AIRCRAFT FIRE EXTINGUISHER  
PRODUCTS.

SUBJECT: INFORMATION REGARDING MOUNTING BRACKET  
REMOVAL AND WEIGHT ASSOCIATED WITH  
REMOVAL.

PURPOSE: THIS SERVICE INFORMATION LETTER (SIL)  
EXPLAINS THE WEIGHT REDUCTION  
ASSOCIATED WITH THE REMOVAL OF MOUNTING  
BRACKETS.

1. INTRODUCTION  
Pacific Scientific has received reports that units utilizing mounting bracket kits sometimes cause confusion. While servicing the issue of missing brackets may cause a unit to seem to be under weight.
2. SCOPE  
This SIL involves all Pacific Scientific fire extinguisher products that use a clamp kit for airframe mounting.
3. REFERENCE  
CMM 26-20-202  
Unit supplements used with CMM 26-20-202
4. COMPLIANCE  
None required. This document is for information only.
5. TOOLS  
None Required.
6. Procedures  
**Do not attempt to accomplish any service procedure without proper technical documents. See: Contacts to obtain technical documents.**
  - A. Determine if the unit is to be weighed with mounting kit.

**SIL NO. 26-0238**  
**PAGE 1 OF 2**  
**December 18, 2002**



HTL/KIN-TECH DIVISION

## SERVICE INFORMATION LETTER

6. Procedures (cont)

B. Installation kit weight is roughly .40 lbs. Add .40 lbs if unit is weighed without clamp assemblies.

C. The weight marked on the unit data plate must reflect the correct configuration. If unit is improperly weighed and marked at filling note if unit is .40 lbs overweight. If unit is at correct pressure and is .40 lbs over weight mark data plate with original charge date and corrected weight on the line below.

7. COST AND AVAILABILITY

Contact below for correct technical data, weight check and unit correction cost.

Pacific Scientific Aviation Services  
Company  
11700 N.W. 102<sup>nd</sup> Rd  
Miami, Florida 33178  
(305) 477-4711  
(305) 477-9799 fax  
SITA: MIAPSD  
[service@pacscimiami.com](mailto:service@pacscimiami.com)

Pacific Scientific Ltd.  
Howarth Road  
Maidenhead  
Berkshire SL6 1AP  
United Kingdom  
+44 (0) 1628 682 200 Phone  
+44 (0) 1628 682 250 FAX  
SITA: LHRPSCR

and

2156 W. Northwest Highway  
Suite 314,  
Dallas, Texas 75220  
(214) 574-4200  
(214) 574-4210 fax

8. APPROVAL

None required.